

## **Getting Started**

Thank you for choosing our signal jammer. Allow us to provide you with an introduction and a clear understanding of the button placements, accessory functions, and other hardware features.

## **Unboxing and Initial Setup**

Carefully open the packaging and retain it for potential future use, such as storage or shipping purposes. Ensure that all components are in good condition. If you encounter any damaged or defective items, please <u>contact us</u> immediately.





Once you've activated the Power Switch, make sure to also enable the DIP switch. The DIP switch is responsible for managing each individual antenna. Each number indicator corresponds to a specific antenna, and when the LED associated with an antenna is illuminated, it indicates that the antenna is operational.

## **Important Notices**

©Prior to initial use, ensure the battery is charged for a minimum of 5 hours.

 © Before initiating the charging process, switch off the power. While the battery is charging, the indicator will illuminate in RED, and it will switch to GREEN once charging is complete.

 O Do not switch on the power supply before connecting all antennas.

- Do not remove antennas while the mainframe is in operation.
- © Ensure proper ventilation when installing the jammer.
- © Position the antennas vertically to the ground for optimal performance.